

Composite Tank Development

- Cryogenic fluid containment
- Storage of chemically unstable fluids

Background of Technology Needs

- Need for reliable, lightweight fuel and oxidizer tanks
 - Engineered to match operating environments
 - Designed to match operating temperatures and pressures, loads, impact resistance, chemical compatibility, permeability, etc.
- Need for cost-effective and scalable manufacturing
- Apply tank technology to lines, ducts, and manifolds

Approach for Achieving Technology Goals

- Develop tooling methods for tank development
- Develop method for producing easily adaptable and scalable vessel liners
- Develop insulation layer or protective barrier for containers
- Identify appropriate fiber/resin system for composite overwrap structures

Tooling Methods

- Multi-segmented metallic
 - Lightweight (cast aluminum)
 - Better performance at higher temperatures (machined steel)
 - Must engineer thermal expansion mismatches between mandrel and liner
- Eutectic salt
 - Easily removed with water
 - Melts at higher temperatures
 - Proved useful for electroplating liners




Tooling Methods

- Urethane foam
 - Ideal for inexpensive and rapid prototypes
 - Difficult to remove from smaller openings
 - Stable for cure cycle of composite overwrap
 - Poor performance for thermal spray



Thermoplastic Liner Options


- Thermally sprayed nylon-6, nylon-11, PVDF, FEP, ETFE, polyethylene
 - Nylon and polyethylene: Easy to process and compatible with fossil fuels
 - Fluorinated polymers: Harder to process but more compatible with hydrogen peroxide
- Extruded PVDF
 - Bonds to graphite/epoxy overwrap
 - Easily scalable to larger tanks
 - Chemically compatible if adhesive also compatible



Electro-Formed Metal Liner Options

Current Options

- Nickel and copper liner (5 & 15 mils)
plated over silver-coated eutectic salt
mandrel
 - Nickel ideal for liquid oxygen compatibility
 - Copper resists hydrogen embrittlement
- Tin
 - Potential for containing hydrogen peroxide
 - Thermally sprayed tin or aluminum provides
conductive plating surface




Future Options

- High-temperature wax mandrels and
segmented metallic mandrels


Thermal/Cryogenic Insulation

- Low-density urethane foam
 - Impact-resistant protective layer
 - Sprayable to approximate thickness
 - Castable in molds
 - Machineable to desired thickness
 - Variable density possible by tailoring formulation and process parameters
- Others materials can be used
 - Phenolic foam or PVC foam



Composite Overwrap

- Liner filament wound with impregnated fibers
 - Epoxy resin system chosen for application
 - Toughened epoxies for cryogenics
 - Oven-curable resins rotisserie cured
 - Lower temperature cure epoxies for foam layer
 - Resin cure temperature matched to liner melting point
- Various fibers to engineer tank performance
 - Carbon, Pbo: High strength, low weight
 - Glass, Aramid fiber: Abrasion resistance
- Protective layer for foam filament wound
 - Fibers and resins chosen for application



Upcoming Activities

- Testing and inspection of tank and duct concepts
 - Long-term storage of 90% hydrogen peroxide
 - Cryogenic testing of tanks for liquid oxygen
- Development of cost-effective 5,000 psi helium pressurant tank
- Fabrication of toroidal tanks with internal slosh/antivortex baffles and external support struts